

## **Cleverscope Model CS320A - CS328A Data Sheet**



## Summary

Cleverscope Model CS320A or CS328A is a USB or Ethernet connected, PC hosted oscilloscope and spectrum analyser. It's easy to use Windows program integrates with standard office applications. Graphs and data can be copied and pasted to other applications, saved or loaded from disk, and printed. The CS320A is the same as the CS328A, except it has not digital inputs.

Cleverscope hardware resources include:

- Two 12 or 14 bit analog channels sampling simultaneously at 100 MSa/sec.
- One external trigger.
- Eight digital inputs sampling at 100 MSa/sec (not CS320A).
- A rear panel I/O connector with a 100 Mbit/sec bi-directional LVDS/RS422 link, and three RS422 outputs.
- Eight Mega samples of storage per channel, providing two or more frames of signal of 20 or 40 ms of storage with 10 ns resolution. (Total storage is 64 Mbytes, distributed over the sample space).
- Moving average (6 time constants) and 20 MHz Anti-alias filter for improved Spectrum Analysis performance and ENOB.
- A dual triggered system allow triggers on edge, slope, period, count conditioned by digital values.
- Triggered LED on the front panel
- Two optional plug-in signal generators, one is 0-10MHz, sine, square or triangle, the other is isolated (300V Cat II) 0-65 MHz sine wave.
- An optional External Sample clock input (range 1-105 MHz).

Cleverscope software resources include:

- Separate, freely moveable, windows to display the signal, a zoomed signal view, and the frequency spectrum of the signal.
- Spectrum analysis with a variety of conditioning windows.
- Signal averaging and filtering.
- Protocol decoding  $-I^2C$ , SPI, UART and parallel bus.



- Matlab live link via Maths process
- Full mathematical functions including + / \* sqrt, transcendental functions, integral differential and filtering. Up to 10 user defined mathematical equations.
- Logging of derived values Frequency, RMS, p-p, period, DC, std dev and marker values.
- Signal measurement, including peak, RMS, DC, pulse width, period and frequency.
- Copy and Paste to other applications.
- Save and Open from disk, including autosave following trigger.
- Continuous save to disk at up to 1.5 MSPS. Pan and zoom over 500G sample space.
- User chosen units and scaling.
- Text annotation of each graph.
- Link two units for 4 channel operation
- 64bit Control Driver with sample code in labview, Matlab, C#, C++, Python and VB .Net

# **Specification**

## Acquisition

Acquisition Outputs	Waveforms: Sampled, Peak Detected, Filtered,
	Averaged in PC, Averaged in Acquisition Unit, and
	Spectrum
Acquisition Modes	Single Shot, Triggered, Automatic, Repetitive (High
	Frequency), Multiple Frame
Acquisition Rate to PC, via USB	20 Frames per second
Acquisition Rate, multiple frame	Continuous capture until buffer is full (2 - 3000 frames
	of 4M - 1300 samples)
Filtering	Moving average filter with $40n - 1.28us$ time constant.
	Resolution improvement to 12 or 14 bits.
	20 MHz anti-alias filter.

### Analog Inputs

Number	2
Input Coupling	DC, AC, GND
Input Impedance, DC coupled, all channels	1 M $\Omega$ ±2% in parallel with 20 pF ±3 pF
Probe Attenuation	1X, 10X
Maximum Voltage between Signal and Common at	300 Vrms (420V peak, duty cycle <50%, pulse width
input BNC	<100 msec)
	For steady state sinusoidal waveforms, derate at 20
	dB/decade above 100 kHz to 10 Vpk at 3MHz and
	above.
Time delay between channels, typical	200 ps
Channel to Channel Crosstalk, typical	-70 dB at 10 MHz, 4V p-p signal.

#### Vertical

Digitizers	12 or 14 bit resolution (depending on option module)
Full Scale Volts Range	20 mV to $\pm$ 20V, 1X probe
Resolution	0.02 mV for 20 mV Full Scale.
Position Range	Full Scale Range as above moved anywhere in the range $\pm 2.5$ V with 10mV resolution for full scale less than 5V, and anywhere in the range $\pm 20$ V with 100mV resolution for full scale greater than 5V.
Analog Bandwidth	100 MHz, -3dB
Instantaneous Capture Bandwidth	25 Mhz



Repetitive Sampling Bandwidth	100 MHz, -3 dB
Analog Bandwidth in Peak Detect Mode	50 MHz
Analog Bandwidth with Anti-Aliasing filter on	20 MHz
Analog Bandwidth with Moving average filter on	0.3 - 20 MHz (6 settings)
Lower Frequency limit, AC coupled	10 Hz, 1x probe, 1Hz, 10x probe
Rise time at the BNC, typical	<3.5 ns
Peak detect response	Captures all pulses >10 ns in duration.
DC Gain accuracy	$\pm 1\%$ for Sample or Averaged acquisition mode
DC Measurement accuracy	$\pm 1\%$ for Sample or Averaged acquisition mode +0.1
	division.
Delta Volts measurement	Volts between any two points, $\pm 1\%$ for Sample or
	Averaged acquisition mode +0.02 division.

### Horizontal

Sample Rate Range	100 MSa/sec to 1500 samples/sec
Waveform interpolation	Sin(x)/x
Record Length	1024 – 4 000 000 samples for each channel
Sec/Div Range	1 ns/div to 5 s/div in 1,2,5 sequence

## Vertical

Sample Rate and Delay time Accuracy	+/50 ppm over any >1 ms interval
Sample Clock jitter, typical	1 ps rms
Delta Time Measurement Accuracy	$(\pm 1 \text{ sample interval} + 50 \text{ ppm} + 0.4 \text{ ns}).$
Position Range	+/- 21.47 secs of the trigger point, with 10 ns resolution.
Captured Sample window duration	1 usec – 40 msec with 10ns resolution
	40  msec - 40  secs with  10  ns - 10  us resolution.
	(Lower sample rates are used for smaller capture buffer sizes)

# Trigger

Number of triggers	2
Trigger sources	Each trigger can be independently set to source from Channel A,
	Channel B, Ext Trig, Link Input, and Digital Inputs 1-8 as a pattern.
Trigger Sensitivity, Edge Triggered	Analog Channels – 0.2 Div from DC to 50 MHz
	External Trigger – 50 mV from DC to 100 MHz
	Digital Inputs – 100 mV from DC to 100 MHz
Trigger Modes	Edge, Pattern, Pulse Duration, Voltage slope, Voltage Window, Count,
	OR. Combination of duration and count.
Trigger Filtering	Noise reject, HF reject, LF reject
Trigger Level Range	Internal: defined by scope graph.
	External: -8 to +18V in 40 mV increments
	Digital: 0 – 8V in 10 mV steps
Trigger Level Accuracy	Internal: ±1%
	External: $\pm 3\% + 50 \text{ mV}$
	Digital: ±3% + 100 mV
Trigger Delay Range	0-21.47 secs with 10ns resolution.



## Digital Inputs (CS328A)

Number	8
Input impedance	$100$ k $\Omega \pm 2\%$ in parallel with 10 pF $\pm 2$ pF
Input voltage range	-16 to + 20V
Threshold range	0 - 8V in 10 mV steps
Threshold sensitivity	100 mV
Sample Rate	100 MSa/sec

#### PC Interface

Types of Interface	USB 2.0 (480 Mbit/sec) or Ethernet (100 MBit/sec)
Effective Throughput rate	USB – 18 Mbyte/sec, Ethernet – 6 Mbyte/sec
Isolation	USB, none, Ethernet – 20 pF, 1500VAC isolation
Ethernet connectivity	DHCP or Point-to-Point or IP addresses. Cable direction auto-sense.

#### Calibration

Calibration method	Automatic self calibration
Calibration Voltage Source	Range ±2.5V
	Resolution 1 mV
	Drift 11 ppm/°C
	Accuracy ±1%
Temperature Compensation	Via Internal temperature sensor, ±1.5°C accuracy

## Displays

Windows	Simultaneous Capture, Tracking, Spectrum, Information, Maths, XY,
	Control Panel and Protocol setup windows
Capture window functions	Defines capture specification for signal acquisition unit, defining
	amount of time before trigger, amount of time after the trigger, lower
	amplitude limit, upper amplitude limit.
	Defines Tracking graph time position, when tracking graph is linked.
	Defines trigger level and direction
	Full zoom and Pan in both axis.
	Annotations.
	Custom colours
Tracking window functions	Displays zoomed section of captured signal. Resolution from 10ns to
	5s/div.
	Full zoom and Pan in both axis.
	Annotations.
	Custom colours
Spectrum window functions	Display spectrum of signal captured in capture window.
	User definable resolution
	Full zoom and Pan in both axis.
	Annotations.
	Custom colours
Maths window function	Displays results of Maths equations.
	Maths equations are user entered expressions involving any of the
	inputs (analog and digital), previous maths equation line results, and
	an arbitrary number of function results (+ - * / sqrt, power, log, ln, all
	transcendental functions, equality functions).
	Provide live Matlab link.
XY window function	Displays XY graph from source (Capture, tracking, spectrum, or
	Maths



Information window functions	Displays automated measurements (see below)
	Used to log derived information values to disk, with a period of
	between $0.05 - 86,400$ secs per sample.
	Live logging to Excel
	DDE live value transfer to Excel.
Control window functions	Provides Trigger settings – analog and digital
	Provides Sample control – single, triggered or automatic.
	Provides access to tools – Pan, Zoom, Annotate
	Controls Frame store
	Controls Spectrum resolution, acquisition method and averaging
Frequency Response Analysis (FRA)	FRA control panel is used to setup up oscilloscope/signal generator to make
	automated measurements of these values vs frequency:
	RMS Amplitude
	Power
	Power Density
	Gain/Phase
	<ul> <li>Impedance + R<sub>ESR</sub> or Q/D Factor or Phase</li> </ul>
	Capacitance + R <sub>ESR</sub> or D Factor or Phase
	<ul> <li>Inductance + R<sub>ESR</sub> or Q Factor or Phase</li> </ul>
	Shunt Impedance (magnitude without phase for low impedances)
	• PSU Gain/Phase - for finding Gain/Phase of powered up power supplies
	• PSU PSRR - for finding PSRR of powered up power supplies
	PSU Output Impedance - for finding Output Impedance of powered up
	power supplies
	<ul> <li>PSU Input Impedance - for finding Input Impedance of powered up power supplies</li> </ul>
	Prohe calibration functions for maximum accuracy
Protocol Setup	Provides protocol setup for I <sup>2</sup> C SPL UART and parallel bus
11010001 Detup	The second second of the second of the second secon

## Frequency Response Analysis Functions (FRA)

The Frequency Response Analysis (FRA) system uses the optional signal generator to provide stimulus for component, system or power supply measurements. The measurements available are shown in the Displays/FRA section of the data sheet. Here are a collection of measurements made using the FRA system (zoom on the PDF to see the detail):



#### cleverscope

plug & play instruments



#### **Example Mixed Signal Window**





#### Measurements

Cursors	Voltage Difference between cursors			
	Time differenc	e between curs	ors	
	Reciprocal of $\Delta T$ in Hertz (1/ $\Delta T$ ).			
Automated measurements	Function	Function	Function	Function
	DC	0 -> 1 Time	DC	A at F
	RMS	1 -> 0 Time	RMS	B at F
	Max	V '1'	Fsignal	A max
	Min	V '0'	Vsignal	A min
	Pk-Pk	V swing	F1	B max
	Std Dev	Overshoot	V1	B min
	Period	Slew rate	F2	Amax at 0 B
	Fundamental	Pulse	V2	Amin at 0 B
	Frequency	Period	F3	Bmax at 0 A
	Fundamental	Pulse	V3	Bmin at 0 A
	Peak amp	Frequency	SINAD	A -3dB L: H
	Pulse	Pulse	THD	B -3dB L: H
	Length Durby Cords	Length Durby Cords	HD2+3	-
	Duty Cycle	Duty Cycle		
Custom units	6 characters			
Custom signal names	20 characters			
Custom scaling	Scale + offset by defining two (Vin, Vout) points			
User definable colours	Signals, Background, Major Grid, Minor Grid			

## Mathematical Functions

Functions over the signal	Differentiation, Integration, Filtering, Power functions, Matlab
	interface, Signal Processing functions
Functions on a data point	Addition, subtraction, multiplication, division, squaring, square root,
	(inverse) sine, cosine, tangent, tangent, log, sign etc. Equality
	operations.
Maximum number of sequential	10
mathematical equations	

## Spectrum Analysis

Frequency Range	User definable, Range = 0- 1/Scope Graph $\Delta T$
	Frequency axis – log or linear.
Analysis Output	RMS Amplitude, Power, Power Density, Gain/Phase
Frequency Resolution	Spectrum has from 1024 to 1048576 points (50 Hz in 50 MHz).
Output type	Volts, Power, Gain/Phase in linear, dB, degree or radian values.
	Custom units can be applied.
Window types	None, Hanning, Hamming, Blackman-Harris, Flat top, Low Sidelobe
Averaging	Moving average, block average, peak hold.
Averaging method	Vector averaging in time domain if triggered.
	RMS averaging in frequency domain if not triggered.

## Protocol Decode

Protocols	I <sup>2</sup> C, SPI, UART and parallel bus.
Protocol decode inputs	Digital Inputs 1-8, External trigger, Channels A, B
	User defined threshold when using analog inputs
Protocol decode variables	Number of bits, Clock edge rising or falling, Bit invert/non Invert,
	Select Hi/Lo, MSB first or not, Number of stop bits.
Output display type	Naming label. Character, Hexadecimal or Decimal Number. Colour.



## Charting

Sampling Rate	1 SPS – 1.5 MSPS
Sample preparation	Peak capture or Moving average filter prior to decimation. Using 1.28us filter with 12 or 14 bit ADC we achieve 16 bits ENOB at 1
	MSPS.
Sample storage	Up to 500 G samples. Samples are stored in multiple smaller files to
	increase speed.
Review capabilities	Zoom and pan anywhere in sample space. Samples are displayed peak
	captured (ie 1us pulse will still be visible in 1 day long sample record).
Export capabilities	Export tab delimited text, binary, or cleverscope format file. Output
	between markers, or current display. Set output depth.

## Data Export

File types output	Cleverscope proprietary, Tab delimited tex (Excel compatible), Excel
	file (for signal information logging).
Live Data output	DDE to Exel, direct placement of data into live Excel sheet
	Live data output to and return from Matlab

### Windows facilities

Standard Functions	Copy and Paste
	Save and Open native format (saves full setup)
	Save and Open tab delimited text file
	Save and Open binary file (start time, dt, data)
	Print with Date/Time, File Name and Description.
	Print Setup
Windows	Dynamically resized
	Can be placed anywhere on desktop
User settable units	6 characters
User settable signal names	20 characters
User settable scaling	Scale + offset by defining two (Vin,Vout) points
User definable colours	Signals, Background, Major Grid, Minor Grid

## Probe Compensator Output

Output Voltage, typical	$2V$ into $>100k\Omega$ load
Output Frequency	1 kHz

### **Power Source**

Source voltage into unit	7 - 15V DC
Power Consumption	6W
Standard power adaptor voltage range	100 – 240VAC 50-60 Hz

#### Environmental

Temperature	Operating: $0^{\circ}C$ to $+40^{\circ}C$	
	Storage: $-20^{\circ}$ C to $+60^{\circ}$ C	
Cooling Method	Convection	
Humidity	0°C to +40°C <90% relative humidity	
	>40°C <60% relative humidity	
Altitude	Operating 3,000 m	
	Non-operating 15,000m	



#### Mechanical

Size	Height Width	35 mm 153 mm
	Depth	195 mm (including BNC)
Weight (approx)	Standard packaging: 1.6 kg	

## Expansion Capability

#### Signal Generator Plug-in CS700A

Function	Generate Sine, Square or Triangle output signals
Generation Method	Direct Digital Synthesis
Output Sampling Rate	50 MSa/sec
Frequency Range	Sine, Square: 0.2 Hz – 10 MHz Triangle: 0.2 – 1 MHz
Resolution	0.003 (<750 kHz) or 0.2 (<10 Mhz) Hz
Accuracy	50 ppm in 1 year, 0-40 deg C
Output Voltage Range	$300 \text{mV} - \pm 5 \text{V}$ p-p including DC offset
Output Voltage Resolution	10 mV
Output Impedance	50 ohm
Output Voltage Offset Range	-4 to +4V
Output Voltage Offset Resolution	10 mV
Frequency Shift Range	Any two frequencies in range 0.2Hz – 10 MHz
Signal to Noise Ratio	-60 dBc typical
Total Harmonic Distortion	0 – 1 MHz : < -60 dBc > 1 MHz: < -45 dBc
Amplitude Flatness	$\pm 0.2 \text{ dB}$
Amplitude Accuracy	$\pm 2\%$
Square Wave Rise/Fall Times	< 12 ns
Protection	Short Circuit Protected ± 10V peak overdrive < 1 min

## Signal Generator Plug-in CS701

Function	Sine Wave Generator with future AWG capability
Frequency Range	0 - 65 MHz (-3 dB)
Frequency Step	50 mHz with 50 kHz upper frequency limit
	10 Hz with 65 MHz upper frequency limit



DAC resolution	14 bit
Output Impedance	50 ohms
Freq Accuracy	50 ppm
SFDR to Nyquist	87 dBc at 10 MHz Fout
Phase Noise	1kHz offset, -150 dBc/Hz
IMD	88 dBc at 10 MHz Fout
Amplitude Range	0 - 6.8V p-p
Offset Range	0 - +/-3.4V (with clipping at +/-3.4V)
AWG	4096 samples maximum at 167.772 MHz sampling rate
	The sample rate may be reduced in steps of 6ns.
	Continuous at 50 ksps
Modulation	Phase, frequency, amplitude
Isolation	300 V RMS, Class III
Isolation Capacitance	7.3 pF (Output BNC shell to Cleverscope Ground)
Common Mode dV/dt	25 kV/µs

## Sampling Channels

Increase in sampling channels	Stack two units on top of each other. Uses two USB links, and Trigger link cable. Delivers 4 analog, and 16 digital channels.
-------------------------------	---

V1.4 8 Aug 2010